

RINA

INSTALLATION

2024-07-10

WARNING ! Installation should be performed by a qualified electrician in accordance with the National and Local Electrical Code.

1

INSERT AIRCRAFT CABLE (A) INSIDE OF CABLE COUPLER (B) AS SHOWN.

2

INSTALL MOUNTING BRACKET BAR (C) INTO 4"OCTAGONAL JUNCTION BOX ON CEILING USING 2-WAYS #8 SCREWS (D) SUPPLIED BY OTHERS. ATTACH 1/4-20" THREADED STUD (E) TO BRACKET BAR (C).

3

PASS POWER CORD / DIMMING CORD THROUGH STRAIN RELIEF (G). INSERT STRAIN RELIEF (G) W/ POWER CORD INTO CLEARANCE HOLE LOCATED ON FEEDER CANOPY (F). SECURE IT IN PLACE.

4a

MAKE ELECTRICAL WIRING CONNECTION INSIDE OF JUNCTION BOX (BY OTHERS). FOR 0-10V DIMMING CIRCUITS, USE PINK & PURPLE WIRES. SEE WIRING DETAIL.

WIRING DETAIL:

POWER FEEDING (color)	USE
White	Neutral
Black	Line 100-347V
GROUNDING	
Green	Ground
0-10V DIMMING	
Pink	Pink
Purple	Purple

4b

MOUNT CANOPY (F) TO CEILING USING CABLE COUPLER (B) & 1/4-20" ROD (E). TIGHTEN IT INTO PLACE.

5

INSERT AIRCRAFT CABLE (A) INTO CABLE GRIPPER (H) ADJUST AIRCRAFT CABLE (A) TO THE DESIRED HEIGHT AND SECURE IT IN PLACE.

6

REPEAT STEPS 1, 2, 4B, 5 FOR NON-FEEDER MOUNTING CANOPY SIDE BEFORE INSTALLING FEEDER CANOPY W/ POWER CORD.

PEERLESS
electric-électrique

INSTALLATION SHEET
Peerless-Electric.com

INCEP[®]TION[®]
PEERLESS CANADA