

OPERATING INSTRUCTIONS

WARNING ! Installation should be performed by a qualified electrician in accordance with the National and Local Electrical Code.

STEP 1: Shut off power to the fixture. Open the fixture lens and remove the existing fluorescent lamps, ballast cover, and lens. Disconnect the ballast from the building's line voltage.



STEP 2: Install the support brackets (x2) and secure with tek screws. **(Optional):** Install side plates (x2). This step is dependent on whether or not there are gaps between the fixture and the existing ceiling grid.



STEP 3: Insert the doorframe of the retrofit into the keyholes of the support brackets and slide the unit into place. Connect power from building to quick disconnect on retrofit kit.



STEP 4: Swing the doorframe assembly up into the fixture frame.



STEP 5: Secure the doorframe kit by locking in the latches.



STEP 6: Restore power to the fixture.

